

Spot Treatment Conductor

Tru Face® Line Corrector Treatment Instructions



For optimal results, use Tru Face® Line Corrector with your Galvanic Spa® II Instrument and Spot Treatment Conductor twice daily, morning and night. Read through these instructions completely before starting your Tru Face® Line Corrector spot treatment. Review your owner's manual for any questions regarding your instrument.

- 1. Attach Spot Treatment Conductor:** If necessary, remove the existing conductor by pressing firmly on the release button. Snap the Spot Treatment Conductor into place, ensuring that the side with the positioning indicator (small etch) matches the display side of the instrument.
- 2. Prepare face for treatment:** Cleanse and tone your face with the Nu Skin® cleanser and toner of your choice.
- 3. Apply Tru Face® Line Corrector:** Apply generously to lines and wrinkles on the target area of your choice (around the eyes, forehead, nose, or mouth). Apply to only one target area at a time. Make sure to leave a thin layer of product on the surface of the skin to better facilitate treatment with the Spot Treatment Conductor node.



4. Program Galvanic Spa® II Instrument for Tru Face® Line Corrector spot treatment:

- Push the selection button twice. The two-fountain icon should appear in the display.
- Watch for the number “1” to appear below the two-fountain icon.
- Select a treatment time by immediately pushing the selection button until the desired amount of time appears, from 1 to 5 minutes for maximum benefits*.

*For smaller, thinner lines or for lines around the sensitive eye area, use a shorter time setting—from 1 to 2 minutes. Otherwise, a longer time setting is recommended—either 3 or 5 minutes.

If an error is made in programming, restart your instrument by pressing the selection button until the two-fountain icon reappears.

- #### 5. Perform treatment with Tru Face® Line Corrector:
- Hold the instrument with a moistened hand, making sure your fingers are touching the chrome panel. Make contact with your skin. You will hear one, two, or three beeps as the instrument automatically sets the current level for your skin type. When you hear the beeps, three arrows will appear in the display, begin lightly massaging targeted area. Hold the instrument so that the oval treatment area is always flat against your skin. Keep the instrument in constant contact with your skin and massage only where Tru Face Line® Corrector has been applied. **Avoid pressing too hard or pulling the skin, and avoid direct contact with the eyes or eyelids.** Repeat Steps 3 through 5 for each subsequent target area on your face. (Rewet your hand as necessary if more than one target area is treated.)

If you lose contact with the chrome panel at any time during your treatment, simply adjust your hold on the instrument and resume your timed treatment. The instrument will beep at 20 second intervals during treatment. When you hear two beeps and see a check mark in the display, your treatment is complete. Turn off the instrument by pressing the selection button until the display is blank. Remove any remaining product from the instrument with a damp towel and dry thoroughly.

- #### 6. Store in a dry place, or on the stand provided, without a conductor on the instrument.



90023855/2